

# MONO SLAB® INSTALLATION INSTRUCTIONS

**1**

Excavate to plus or minus 1/2 inch.



**2**

Beginning at a corner, place the first Mono Slab® EZ Form.



**3**

Place the next Mono Slab® EZ Form, butting it in firm contact with the previous form.



**4**

Connect Mono Slab® EZ Form with a 2x12x8' screed board, staggering the seams. Place two stakes per 8' length.



**5**

Lightly backfill the exterior of the forms.



**6**

Starting at the highest point in the foundation, lift the screed board (2x12x8') to achieve a perfect level.



**7**

Secure screed boards with Level Up Extension Brackets.



**WHERE YOU  
CAN FIND US!**



FACEBOOK



INSTAGRAM



YOUTUBE



WEBSITE

OFFICE: 208-558-5200 [WWW.MONOSLABEZFORM.COM](http://WWW.MONOSLABEZFORM.COM)  
[INFO@MONOSLABEZFORM.COM](mailto:INFO@MONOSLABEZFORM.COM)